



DT-179

CARBON MONO-OXIDE DATA LOGGER

This product is a Carbon Monoxide Chroma Datalogger, which measures in the range of 10–1000 PPM. User can set up the sampling rate, high/low alarm value and start mode and can also operate the software in windows 98, 2000, XP, vista or win 7 system to download the data to PC by USB interface, then draw graphics by the data, realizing print and export data function. The datalogger provides a lithium battery of one year's service life; its function mode is indicated by Red, Yellow and Green LED light flash.

FEATURES

- Memory for 32,000 Readings
- Draw Graphics Curve by the Data through the PC Software
- Selectable Sampling Interval: 1s to 12hr,
- Operating Status Indicated by Red, Yellow and Green LED Light
- Data Download to PC Software by USB Interface
- Too Low / too High Alarm Value Setup
- Two Modes (manual and automatic) to start Recording Data
- Low Battery Alarm
- Sensor: Carbon Monoxide Sensor
- Operating Temperature: -4 to 122°F (-20 to 50°C)
- Operating Humidity: 15% - 90% RH
- Weight: 49g
- Size: 145 x 35 x 30mm

Unit	Range	Resolution	Accuracy
PPM	10 – 1000 PPM	1 PPM	± 6 PPM

INCLUDED ACCESSORIES

Instruction Manual, Battery, Test Report.