

FLIR T620 & T640

High performance thermal imaging with on-board 5MP visual camera, interchangeable lens options, auto-focus, and large 4.3" touchscreen LCD

These thermal cameras combine excellent ergonomics with superior image quality, providing the ultimate image clarity and accuracy plus extensive communication possibilities.

Highest IR resolution in its class – Crisp thermal images with 307,200 pixels (640×480) for the best detection, pictures, and temperature measurements from long range.

Precision focus – Manual control and the fastest auto-focus available for the ultimate clarity, accuracy, and efficiency.

MSX® enhancement – Multi-Spectral Dynamic Imaging adds visible spectrum definition to IR images in real time for excellent thermal detail to help you instantly recognise the problem locations.

Auto orientation – Automatically orients onscreen temperature measurement data whether in portrait or landscape mode.

Field of View (FOV) match – Option to match the visible camera field of view to the IR FOV for better documentation.

GPS and compass – Automatically adds geo-location data and camera pointing direction to images to include in reports.

Programmable button - Provides easy access to favorite functions.

Wi-Fi Connectivity – Send images and data to smartphones and tablets and share critical information quickly with the FLIR Tools Mobile for Apple[®] and Android[™], featuring live video streaming and remote control via the mobile device.

Accuracy – Calibrated within $+/-2^{\circ}C$ or $+/-2^{\circ}M$ of reading.

High temperature range – measures to 2000°C targeting electrical/industrial applications (T620 to 650°C).

Scalable P-i-P - Overlay thermal images onto visible photos as an alternative reference.

Multiple measurements - Report all the details with 10 measurement spots, 5 box areas, Delta T temperature differential, isotherm, and auto hot/cold markers.

METERLINK® – Wirelessly transmit vital diagnostic data from clamp and moisture meters directly to the camera for annotating thermal images to further support findings.


Annotation – Add voice comments via Bluetooth headset and text notes from the touchscreen keypad. Sketch circles, pointers and notes on stored IR/visual images.

InstantReport - Create PDF document directly from the camera.

Includes - See specification chart on back.



Built-in 5MP Digital camera, LED lamps, laser pointer, image capture button and auto/manual focus capability. 120° rotating optical block




Sketch on IR/visual -use touchscreen to draw circles, pointers, etc. on stored images





Wi-Fi connectivity



Original IR Image on the left and with MSX™ enhancement on the right image



Auto orientation keeps on-screen data upright













Utility market — Use infrared cameras to locate problems, detect hot spots and other problems before they turn into costly failures & production downtime or electrical fires.

Electrical inspections — With FLIR thermal imaging cameras electrical contractors can scan electrical cabinets/panels and components for a non-contact view of conditions.

Imaging specifications

FEATURES	FLIR T620	FLIR T640
Temperature range	-40°C to 650°C (-40°F to 1202°F)	-40°C to 2000°C (-40°F to 3632°F)
Thermal sensitivity (N.E.T.D)	<0.04°C at 30°C	<0.035°C at 30°C
Zoom	4X continuous	8X Continuous
Focus	Manual or automatic (one shot)	Continuous, manual or automatic (one shot)
Viewfinder	_	Color viewfinder for viewing images in bright or sunny conditions
Profile measurement analysis	_	Shows a live graph of temperatures across a line on the image
COMMON FEATURES		
Sketch on IR/visual	Draw on stored images right on touchscreen	
Measurement presets	6 presets: center spot; hot spot (box max); cold spot (box min): no measurements; user preset 1; user preset 2	
Multi-Spectral Dynamic Imaging (MSX)	IR image with enhanced detail presentation	
GPS	Location data automatically added to every image from built-in GPS	
Compass	Indicates direction camera is pointing for target documentation	
Frame rate	30Hz	
Field of view/minimum focus distance/FOV Match	25° x 19° / 0.25m / Field of View Match where Digital Image FOV adapts to the IR lens	
Detector type - focal plane array (FPA) uncooled microbolometer	640 x 480 pixels	
Spectral range	7.5 to 14µm	
Lens	25° or 45° models (optional 7°, 15°, 25°, 45°, 80°, Close up 100μm, 50μm lenses available)	
Display	Built-in touch-screen 4.3" color LCD (800 x 480 pixels)	
Image modes	Thermal/Visual/P-i-P (Resizable and movable)/MSX and thumbnail gallery	
Automatic image adjustment	Continuous/manual; linear or histogram based; possible to lock max, min or span temperature	
Manual image adjustment	Level/span/max/min	
Image storage	1000 radiometric JPEG images (SD card memory)	
Image annotation	Voice (60 sec); text comments, Sketch	
Periodic image storage	7 seconds to 24 hours (IR) and 14 seconds to 24 hours (IR and visual)	
Video lamp	Bright LED lamp	
Laser pointer classification/type	Class 2/Semiconductor AlGalnP Diode Laser: 1mW/635nm (red)	
Set-up controls	Mode selector, color palettes, configure info to be shown in image, local adaptation of units, language, date and time formats, and image gallery	
Measurement modes	10 Spotmeters, 5 Box areas, Isotherm, Auto hot/cold spot, Delta T	
Measurement correction	Reflected ambient temperature & emissivity correction	
GPS	Location data automatically added to every image from built-in GPS	
Video recording in camera and video streaming	Non-radiometric IR-video recording (MPEG-4 to memory card), Visual and Radiometric IR-video streaming (Full dynamic to PC using USB or Wi-Fi), and Non-radiometric IR-video streaming (MPEG-4 using Wi-Fi and uncompressed colorized video using USB)	
Battery type/operating time	Li-lon/ 2.5 hours, Display shows battery status	
Charging system	In camera AC adapter/2 bay charging system	
Shock/vibration/encapsulation/safety	25G, IEC 60068-2-29 / 2G, IEC 60068-2-6 / IP54; EN/UL/CSA/PSE 60950-1	
Dimensions/weight	143x196x94mm/1.3kg, including battery	
Accessories included	SD Memory Card, 100-260V AC adaptor/charg battery charger, power supply (with multi-plugs) Bluetooth® headset, lens cap, neckstrap, and he	, FLIR Tools™ software, USB cable, video cable,

Ordering information

	FLIR T620 Thermal Imaging IR Camera (640x480) with Wi-Fi and standard 25° Lens FLIR T620 Thermal Imaging IR Camera (640x480) with Wi-Fi plus 45° Lens
55902-2502	FLIR T640 Thermal Imaging IR Camera (640x480) with Wi-Fi and standard 25° Lens





ACCESSORIES

ACCESSONIES
T197914 IR lens, f=41.3 mm (15°) with case
T197922 IR lens, f=24.6 mm (25°) with case
T197915 IR lens, f=13.1 mm (45°) with case
T198059 Close-up IR lens, 2.9x (50 μm) with case
T198060 Close-up IR lens, 5.8× (100 μm) with
case
T198166 IR lens, f=88.9 mm (7°) with case and
support
T198065 IR lens, f=6.5 mm (80°) with case

 T198066
 Close-up IR lens, 1.5x (25 µm) with case
 T198625
 Hard transport case

 T910814
 Power supply, incl. multi plugs
 T198495
 Pouch

 T198506
 Li-lon Battery pack 3.7V 29Wh
 T198497
 Large eyecap

 T911230ACC
 Memory card SDHC 4 GB
 T198498
 Tripod Adapter

 1910423
 USB cable Std A <-> Mini-B
 T198496
 Stylus pen

 T198509 Cigarette lighter adapter kit, 12 VDC, T198499 1.2 m/3.9 ft. T197771ACC . Bluetooth
T910930ACC . HDMl type C to DVl cable 1.5 m T198583 FLIR Tools
T910891ACC . HDMl type C to HDMl type A cable 1.5 m T911093 Tool belt

T197771ACC . Bluetooth Headset T198583 FLIR Tools+ (license only)



FLIR Commercial Systems Luxemburgstraat 2 2321 Meer Belgium Tel.: +32 (0) 3665 5100 Fax: +32 (0) 3303 5624 E-mail: flir@flir.com

FLIR Systems AB

Sweden Tel.: +46 (0)8 753 25 00

FLIR Systems UK Tel. : +44 (0)1732 220 011 FLIR Systems GmbH

Germany Tel. : +49 (0)69 95 00 900

FLIR Systems France Tel.: +33 (0)1 60 37 55 02

FLIR Systems Italy Tel.: +39 (0)2 99 45 10 01

FLIR Commercial Systems

Spain Tel. : +34 91 573 48 27

FLIR Systems, Middle East FZE Dubai - United Arab Emirates Tel. : +971 4 299 6898

FLIR Systems Russia Tel.: + 7 495 669 70 72

..... Neck strap