



CALL TOLL FREE **1-800-373-9989**

Splashproof Digital Torque Wrenches

GEK-A Series

Standard Features

- Splashproof protective covers* allow operation and comply with IPX4
- Rugged, precision forged construction
- Five programmable Go/No Go torque presets ideal for frequent operations.
- Selectable Units: lbf-in, lbf-ft, kgf-cm, N-m
- Peak, peak with auto zero reset and Real Time modes
- High accuracy $\pm 1.5\%$ F.S. both CW and CCW directions
- Battery-Operated (Panasonic CR2354)
- ISO-6789 Compliant
- Calibration certificate traceable to NIST and carrying case included



*6 to 12 month replacement cycle

GEK-A Splashproof Digital Torque Wrenches are ideal for use in wet environments. The wrench features a flexible membrane cover with an IPX4 rating. The flexible membrane allows for easy operation of the wrench while providing protection against splashing water. Splashproof Digital Torque Wrenches have forged steel heads and feature unique power sensors in the ergonomic handles. The unique torque sensors inside these wrenches, which accurately detect and analyze load applied to the grip, enable more precise torque measurement regardless of hand position, unlike other loading point sensitive wrenches.

The torque wrenches measure in peak mode, peak with auto zero reset, and real time. Five programmable Go/No Go torque presets stored in memory enable users to check frequently used values. The presets alert the user with an intermittent signal at 90% and a continuous signal at 100% of the preset torque value using LED and audible indicators (Presets cannot be set at less than 10% of capacity). Selectable units of lbf-in, lbf-ft, kgf-m, and N-m. Uses a lithium coin battery, Panasonic CR2354.

RANGES

Accuracy: $\pm 1.5\%$ F.S. ± 1 LSD

More Ranges ▶

<u>Model</u>		GEK030-R2E-A	GEK030-C3E-A	GEK060-R3E-A	GEK085-R3E-A	GEK135-R4E-A	GEK200-
Capacity	lbf-in	13.4~265.4	13.4~265.4	13.5~531.0	19.0~752.0	28~1195	46~1770
	lbf-ft	1.12~22.12	1.12~22.12	1.15~44.25	1.60~62.70	2.3~99.5	3.8~147.4
	kgf-m	0.160~3.060	0.160~3.060	0.160~6.120	0.21~8.66	0.32~13.76	0.55~20.
	N-m	1.50~30.00	1.50~30.00	1.50~60.00	2.0~85.0	3.1~135.0	5.2~200.
	Drive	1/4"	3/8"	3/8"	3/8"	1/2"	1/2"

Accuracy: $\pm 1.5\%$ F.S. ± 1 LSD

More Ranges ▶

Model		GEK085-W36E-A	GEK135-W36E-A	GEK200-W36E-A
Capacity	lbf-in	19.0~752.0	28~1195	46~1770
	lbf-ft	1.60~62.70	2.3~99.5	3.8~147.4
	kgf-m	0.21~8.66	0.32~13.76	0.55~20.40
	N-m	2.0~85.0	3.1~135.0	5.2~200.0

IMADA, Incorporated 3100 Dundee Rd., Suite 707, Northbrook, IL 60062 © Copyright 2019
 ISO 9001 Registered & ISO/IEC 17025 Accredited Phone: 847-562-0834 Fax: 847-562-0839