



CALL TOLL FREE **1-800-373-9989**

T-Peel Tester

MX2-110 Test Stand
ZT/DST Digital Force Gauge
Gripping Attachments


T-Peel Tester Standard Features

- Wide speed range: 0.4 – 12 in/min speed is set digitally (optional speed ranges available)
- Screw drive system and high performance brushless motor provides smooth and powerful operation over the entire speed range.
- Selectable Manual, Increment, and Force Control (with ZT Series gauges) modes
- Easy-to-use program dial and menu screens control mode, speed, timer and cycles
- MX2-110 Stroke: 9.4" (240mm)
- Max clearance 9" (with extender 14")
- Force gauge units are selectable: Newton, lbf and kgf
- Force gauge output: USB (ZT), RS-232C, Digimatic and analog outputs

The T-Peel Tester is an integrated testing system specifically for T-Peel or 180 degree peel applications. Perform quick and efficient T-peel tests with the GT-30 vise and FC-40 film grip, MX2-110 motorized test stand, and ZT Series / DST digital force gauge.

The MX2-110 test stand provides smooth, consistent speed essential for peel testing. The Imada ZT or DST force gauges feature convenient push buttons to select measuring units, measuring modes and include a USB (ZT) or RS232 port for data downloads.

Specify Imada ZT or DST force gauge capacities and you're ready to test Velcro, tapes and other materials.



IMADA, Incorporated 3100 Dundee Rd., Suite 707, Northbrook, IL 60062 © Copyright 2019
ISO 9001 Registered & ISO/IEC 17025 Accredited Phone: 847-562-0834 Fax: 847-562-0839