# PEN UV LIGHT METER

Model: PUV-360 *ISO-9001, CE, IEC1010* 







The Art of Measurement

## **PEN UV LIGHT METER**

Model: PUV-360

#### **FEATURES**

* Pen type, high quality UV meter.
* Ultra-violet irradiation measurement for UVA & UVB.
* UV detector spectrum from 290 nm to 390 nm.
* Two ranges : 2,000 uW/cm^2, 20 mW/cm^2, auto range.
* Exclusive UV sensor structure.
* Sensor with cosine correction filter.
* Build Zero button.
* Microprocessor circuit provides high reliability and
durability.
* All in one, meter with sensor probe, convenient
for user operation.
* LCD display, easy readout.
* Compact housing case.

APPLICATIONS
--------------

#### Industrial :

- \* Monitoring blue light radiation hazards in welding.
- \* UV sterilization
- \* Graphic arts.
- \* Photochemical matching.
- \* UV EPROM erasure.
- \* Photoresist exposure.
- \* Curing of inks, adhesives and coatings.

### Laboratory :

- \* Weathering " degradation studies."
- \* UV sterilization
- \* Virology.
- \* Microbial genetics.
- \* DNA research. \* Biologic hoods.
- \* General laboratory use.

#### **SPECIFICATIONS**

or con rown ones				
Display	LCD size: 28 mm x 19 mm.			
UV sensor	Band pass 290 nm to 390 nm.			
spectrum				

+ 1	161 11 11 1 11 1				
^ Appearance and spe	ecifications listed in this	brochure are subject t	to change	without noti	ce.
		,	5		

Measurement	Range 1 : 2,000 uW/cm^2 :		
ranges &	1999 uW/cm^2 x 1 uW/cm^2		
resolution	Range 2 : 20 mW/cm^2 :		
	19.99 mW/cm^2 x 0.01 mW/cm^2		
	* Auto range		
Accuracy	± ( 4 % FS + 2 dgt ). FS : full scale		
	* Calibration is executed under the UVA light &		
	and compare with the standard UVA light meter		
	* Spec. tested under the environment RF Field		
	Strength less than 3 V/M & frequency less than		
	the 30 MHz only.		
Sensor structure	The exclusive UV photo sensor with		
	the cosine correction filter.		
Circuit	Custom one-chip of microprocessor LSI		
	circuit.		
Buttons	Power button, Hold button,		
	REC ( record ) button.		
Sample Time	Approx. 1 sec.		
Over Range	Indication of " ".		
indication			
Power off	Auto shut off saves battery life.		
Weight	190 g/ 0.2 LB.		
Operating	0 to 50 ℃.		
Temperature			
Operating	Less than 85% R.H.		
Humidity			
Power Supply	DC 1.5 V battery ( UM4/AAA ) x 4 PCs.		
Power	Approx. DC 5.5 mA.		
Consumption			
Weight	190 g/ 0.2 LB.		
Dimension	210 x 49 x 40 mm (8.3" x 1.9" x 1.6")		
Accessories	Instruction manual 1 PC		
Included	Light Sensor protection cover 1 PC		
Optional	Soft carrying case with sash		
Accessory	( 210 x 80 x 50 mm ), Model : CA-52A		
ithout notice.	0906-PUV360		