

COLORCATCH 3

VF0705

DATASHEET

PRODUCT DESCRIPTION

COLORCATCH 3 is the first colorimeter which measures and transmits via Bluetooth® the true colour directly to an iPod touch, an iPhone or an iPad. It allows to instantly apply the true colour directly to a picture (building, wall, dress, object etc.) taken by the iPhone. Thanks to COLORCATCH 3 and «Colorix.com Pro» App for iPhone it's all done in less than 2 minutes and in only 3 steps

**BUSINESS**

Protective Coatings, Corrosion Control, Coating Laboratories, Paint Production, Surface Finishing, Powder Coating, Decorative Coatings, Building Maintenance

FEATURES

- Simply in use, only 1 button
- Standard delivered with RAL and NCS colors (more than 2100 colors), more color cards you can download from the internet.
- Suitable for measuring on rough surfaces
- Independent of color or paint manufacturers

SCOPE OF SUPPLY

- CorlorCatch3 incl. RAL and NCS colors
- Nylon belt holder
- Battery
- Manual
- 3 calibration plates
- USB cable

ORDERING INFORMATION

VF0705 – TQC ColorCatch3

SPECIFICATIONS

Battery:	9V alkaline type 6LR61
Capacity:	over 2000 measurements
Memory:	over 100.000 colors
Languages:	English, French, German, Italian, Spanish, Portuguese, Dutch, Turkish, Czech, Slovenian, Catalanian, Finish and Polish
PC communication:	USB
Size:	120 X 40 X 35 mm

Weight: 99 gr (without battery)
Warranty: 2 jaar
Country of origin: Zwitserland

USE

1. Take a picture with your iPhone (building, room, etc.)
2. Use COLORCATCH 3 to select, measure and transmit the real colour to your iPhone or iPad. There are up to 150 colour cards available and downloadable for the COLORCATCH 3 through www.colorix.com/update. For colour cards not listed, please contact us.
3. Apply the selected colours into the picture on your iPhone. In less than 2 minutes you have modified your image using new colours, ready to present it to your customer, send it as e-mail to your office, order the paint or change it once again to look different.
With COLORCATCH 3 and «Colorix.com Pro» App for iPhone you always have the true colour at your fingertips.
«Colorix.com Pro» App for iPhone contains all NCS®© and RAL Classic colour references as well corresponding L*a*b*, sRGB, CMYK and LRV values.
The owners of COLORCATCH 3 can download other color cards in the «Colorix.com Pro» App.

COLORCATCH 3 is Made for:

- iPod touch (5th generation)
- iPod touch (4th generation)
- iPod touch (3rd generation)
- iPod touch (2nd generation)
- iPhone 5
- iPhone 4S
- iPhone 4
- iPhone 3GS
- iPhone 3G
- iPad mini
- iPad (4th generation)
- iPad (3rd generation)
- iPad 2
- iPad

SPECIAL CARE

- Clean the instrument using a soft dry cloth. Never clean the instrument by any mechanical means such as a wire brush or abrasive paper. This may cause, just like the use of aggressive cleaning agents, permanent damage.

SAFETY PRECAUTIONS

- The ColorCatch 3 is an accurate and sensitive instrument, it should be treated as for example a digital camera

DISCLAIMER

The right of technical modifications is reserved.

The information given in this sheet is not intended to be exhaustive and any person using the product for any purpose other than that specifically recommended in this sheet without first obtaining written confirmation from us as to the suitability of the product for the intended purpose does so at his own risk. Whilst we endeavour to ensure that all advice we give about the product (whether in this sheet or otherwise) is correct we have no control over either the quality or condition of the product or the many factors affecting the use and application of the product. Therefore, unless we specifically agree in writing to do so, we do not accept any liability whatsoever or howsoever arising for the performance of the product or for any loss or damage (other than death or personal injury resulting from our negligence) arising out of the use of the product. The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development.